

IMPORTANT:

INTERNAL SHOWER
MEASUREMENTS ARE REQUIRED

STAND INSIDE THE SHOWER CUBICLE
AND MEASURE THE 2 WALLS
THAT BELONG TO THE BATHROOM

Q: HAS THE SHOWER GOT A MOULDED
CORNER GOING TO THE TOP?

A: YOU NEED TO DOWNSIZE THE MODEL.

Q: IS THE SHOWER ALCOVE OR FRAMELESS?

A: ENSURE YOU ORDER THE RELEVANT
DIY KIT TO SUIT.

IF IN DOUBT, PLEASE CONTACT
YOUR LOCAL DISTRIBUTOR.

SQUARE SHOWERS

710mm to 760mm	R650
760mm to 860mm	S700S
860mm to 960mm	S800S
960mm to 1180mm	S900L

RECTANGULAR SHOWERS

Less than 760mm wide x up to 980mm long	R650
Less than 760mm wide x up to 1180mm long	R650L
Between 760mm to 860mm wide x up to 980mm long	S700S
Between 760mm to 860mm wide x up to 1180mm long	S700L
Between 860mm to 960mm wide x up to 1180mm long	S800L or RC700L
Between 960mm to 1180mm wide x up to 1180mm long	S900L or RC700L

5 SIDED 'TRIANGULAR' SHOWERS

Less than 875mm on the wall sides	R650
875mm to 980mm	T800S
Over 980mm to 1180mm	T800L

ROUND FRONT SHOWERS – CURVED DOORS

Less than 760mm on the wall sides	R6500S
760mm to 900mm	C700S
800mm x 1200mm	R650L
900mm x 1200mm	C800L or RC700L